

OPERATION & MAINTENANCE

Spindles revolve 1/2 revolution for each operation and then return to their original position and operate independently. Roll core prevents access to release pin and cannot be removed from spindle until exhausted and screw is loosened with key. Unit is replenished by releasing a concealed pin which in turn releases a spring lock mechanism on spindle.

TECHNICAL INFORMATION / PRODUCT PROPERTIES

Property	Value
Dimensions	13" [330] W x 1-3/4" [45] H x 4-3/4" [120] D
Construction	Aluminum Casting with Satin-Matte, Silver-Grey Finish
Mounting	Surface Mounted
Capacity	Holds two (2) rolls of standard core roll toilet paper up to 6" Dia. [Ø152]

INSTALLATION

Unit is surface mounted on wall or partition using #10 self-threading screws (by others). For compliance with 2010 ADA Accessibility Standards, unit should be installed so that tissue roll centerline is between 44" [1118] maximum above finished floor (AFF) and 19" [483] minimum AFF.

OPTIONS
WARRANTY

One (1) Year from date of Invoice